

HD Video Wall Controller with Mixed inputs

Operating Instructions



Dear Customer

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

1. FEATURES

- Support USB/VGA/Composite/HDMI input.
- Select 1 of 4 source and distribute to 4 displays.
- Create a 2x2 Video Wall Controller from any source to four displays.
- Support multi-level cascading to creat 3x3, 4x4...Video Wall (Max 10x10).
- Support 180° rotation.
- Support resolution up to 1080p Full HD.
- Support Panel control, IR control, RS232 control.

2. NOTICE

Our company reserve the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

3. TABLE OF CONTENTS

Specifications
Package Contents
Panel Descriptions
Connecting and Operating
Typical Application
Remote Control Instruction
RS232 Control
Maintenance
Product Service
Warranty


4. SPECIFICATIONS

Operating Temperature Range	0 to +35°C (32 to +95°F)
Operating Humidity Range	5 to 90 % RH (no condensation)
Input Video Signal	0.5-1.0 volts p-p
Input DDC Signal	5 volts p-p (TTL)
Video Format Supported	DTV/HDTV: 1080P/1080i/720P/ 576P/480P/576i/480i
Audio Format Supported	LPCM
Input ports	1xHDMI, 1xUSB, 1xVGA, 1xAV
Output ports	4xHDMI
Splitter mode	1x4 HDMI Splitter
Video wall mode	2x2,3x3,4x4.....10x10 video wall
Control Way	Panel control, IR control, RS232 control
Power consumption	15watts(Maximun)
Dimension (mm)	L380.6XW136.6XH43.5 mm
Weight	1725g


5. PACKING CONTENTS

- 1) Main Unit: HD Video Wall Controller
- 2) 1x Power supply 5V4A
- 3) 4x Screws
- 4) 2x detachable mounting ears
- 5) 1x IR Cable
- 6) 1x Remote controller
- 7) Operating Instructions

6. PANEL DESCRIPTIONS




Rear Panel



- | | | |
|---------------------|--------------------|---------------------|
| 1. Power input port | 2. IR Ext port | 3. RS232 port |
| 4. USB input port | 5. HDMI input port | 6. VGA input port |
| 7. Audio input port | 8. CVBS input | 9. L /R Audio input |
| 10. Audio output | 11. HDMI output | |

Right Panel



1. DIP switch for EDID choosing

000001	Setting for Output1
000010	Setting for Output2
000100	Setting for Output3
001000	Setting for Output4
010000	Turn on Multi-function button "All"
100000	Turn on "Splicing setup" mode


If you need make splicing setup for 4 HDMI outputs, you can set to "001111"

7. CONNECTING AND OPERATING


- 1) Connect the sources into the video wall controller and Press the button on the remote. to choose the input Signal (VGA, HDMI, USB, AV input).
- 2) Connect HDMI OUT to display equipments.
- 3) Power up the Video Wall Controller.
- 4) Control the Video Wall Controller by Panel button / DIP Switch / Remote / RS232 Command.

8. Typical Application


Application 1: Split a single source to 4 displays




Application 2: 2x2 Video Wall Displaying



Application 3: Multi-Level Cascading (Max 10x10 Video Wall)



9. Remote Control Instruction



Note 1: ③④⑤⑥ is under USB mode.

Note 2: ⑫ is Multi-function Button.

2.1. Press button “ALL”, the “ALL” indicator will turn green, then press “” into the main menu.


2.2 Under USB input mode , press button “ALL” for all the setting

2.3. Press button “ALL”, then press ⑬, ⑯ to adjust the volume


9.1 Language Setting

9.1.1 The main menu language Settings

1. Press “All” button, the “All” indicator will turn green, then press “” to enter into the main menu.




2. Move the left or right arrow, enter into the below interface, choose “OSD Language English”, then press “Ok”.




3. Choose the required language, then press “OK”, press “” back to the main menu.




9.1.2 Language setting for each output

1. Press the Output No on the remote and press “A screenshot of a video player interface showing an OSD menu. The menu is displayed on a dark background. At the top, a yellow triangle points to the 'OSD Language English' option, which is highlighted with a yellow bar. Below it are 'Menu Reset', 'Edge Adjust', and 'MIRROR'. To the left of the menu is the word 'OPTION' and a left arrow. To the right is a right arrow. Below the menu is a yellow triangle pointing down. At the bottom of the screen, there is a video player control bar with a play/pause button, a progress bar, and a volume icon.

9.2 Mirror Function (180°Rotation)

1. Press the Output No on the remote, the press “A screenshot of a video player interface showing an OSD menu. The menu is displayed on a dark background. At the top, a yellow triangle points to the 'OSD Language' option. Below it are 'Menu Reset', 'Edge Adjust', and 'MIRROR Off', which is highlighted with a yellow bar. Below that is 'Splicing SETUP'. To the left of the menu is the word 'OPTION' and a left arrow. To the right is a right arrow. Below the menu is a yellow triangle pointing down. The background of the video player shows a dark, textured image.




9.3 Splicing Setup:

1. Press the Output No on the remote or use DIP Switch to choose the output, the relative indicator will turn green, then press “”.

For example, if you need make splicing setup for output 1 to output4, press “1”, “2”, “3”, “4” on the remote, the indicator “1” to indicator “4” will turn green , then press “”.



2. Choose "Splicing SETUP", When the Horizontal Count and Vertical Count is the same, there will be no deformation on the image.




3. When cascade for NXN video wall , the output which cascade for next layer should be set as "1x1", other outputs should be set as your required "NXN".

For example, if you need cascade for "3x3", the output 1 need to connect with next Video Wall Controller , then the output 1 should be set as "1x1", output2 to output4 should be set as "3x3".


4. After setting the Horizontal Count and Vertical Count, press "  " to turn on /off the video wall mode

9.4. Menu Reset


Choose "Menu Reset" to restore factory setting.



9.5. Edge Adjust.




9.6 Scroll Text (Support CVBS/VAG/HDMI input modes)



1. Create a text document named "ARICH.TXT" under the USB DISK, enter the required content in the document.
2. Insert the USB Disk into the USB port of product.
3. Press "All" on the remote or set the DIP Switch to "010000" , then press "  ".



4. Move the left or right arrow to choose "Scroll Text".



5. Enter "Scroll Text", you can set the Font size, Background Color, Font color, Flow Speed.




6. Turn on the Function, then re-power the Video Wall controller, there will be scroll text on the display.






9.7 USB Disk Input Mode

1. Choose USB input, press "ALL" button on the remote controller, then you can select the required file to play.



2. Press "OK" button when playing the video or displaying pictures.







3. Support JPG、PNG, BMP format pictures
4. Support MP3, FLAC format audio files.
5. Support AVI,WMV,MPG,MP4,RMVB video files
6. Support TXT format file


9.8 CVBS/HDMI input mode:

You can set as 16:9 or 4:3 in this mode.



9.9 VGA input mode






10. RS232 Control

- 1). Open CommUart Assistant.
- 2). Comport setting:

Baud Rate:	115200 bps
Parity:	None
Data Bits:	8 bit
Stop Bits:	1 bit

- 3). Enter Port Command in Send options.



Command	Features
99 06 FF FF	Show Panel no for all HDMI outputs
99 07 FF FF	Hide panel no for all HDMI outputs
79 92 FF	AV input
79 93 FF	VGA input
79 94 FF	HDMI input
79 95 FF	USB input
All bellowing command is only effective for the selected output, please choose the output before sending command.	
79 19 X	Select from output1 to output4 (X: 1-4).
79 1A X	Cancel the output
79 1B FF	Choose all the outputs
79 1C FF	Cancel all the output
79 35 FF	Still image
79 36 FF	Cancel still image
79 88 FF	Image horizontal Stretching
79 89 FF	Image horizontal Compression
79 8A FF	Image vertical stretching
79 8B FF	Image vertical stretching
79 8C FF	Panel no +
79 8D FF	Panel no -
79 8E FF	Splicing on
79 8F FF	Splicing off
79 90 FF	Mirror on (180°rotation)
79 91 FF	Mirror off
69 73 FF	Open the menu
69 63 FF	Up
69 83 FF	Down
69 72 FF	Left
69 74 FF	Right
69 49 FF	Enter
69 48 FF	Back
79 10 FF	Increase brightness
79 11 FF	Decrease brightness
79 48 FF	Brightness reset
79 12 FF	Increase the contrast
79 13 FF	Decrease the contrast
79 49 FF	Contrast reset

MAINTENANCE

Clean this unit with a soft, dry cloth. Never use alcohol, paint thinner or benzene to clean this unit.

PRODUCT SERVICE

1) **Damage requiring service:**

The unit should be serviced by qualified service personnel if:

- (a) The DC power supply cord or AC adaptor has been damaged;
- (b) Objects or liquids have gotten into the unit;
- (c) The unit has been exposed to rain;
- (d) The unit does not operate normally or exhibits a marked change in performance;
- (e) The unit has been dropped or the cabinet damaged.

1) **Servicing Personnel:** Do not attempt to service the unit beyond that described in these operating instructions. Refer all other servicing to authorized servicing personnel.

3) **Replacement parts:** When parts need replacing ensure the servicer uses parts specified by the manufacturer or parts that have the same characteristics as the original parts. Unauthorized substitutes may result in fire, electric shock, or other hazards.

4) **Safety check:** After repairs or service, ask the servicer to perform safety checks to confirm that the unit is in proper working condition.

WARRANTY

If your product does not work properly because of a defect in materials or workmanship, our Company (referred to as "the warrantor") will, for the length of the period indicated as below, **(Parts(2)Year, Labor(90) Days)** which starts with the date of original purchase ("Limited Warranty period"), at its option either(a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor.

During the "Labor" Limited Warranty period there will be no charge for labor.

During the "Parts" warranty period, there will be no charge for parts. You must mail-in your product during the warranty period. This Limited Warranty is extended only to the original purchaser and only covers product purchased as new. A purchase receipt or other proof of original purchase date is required for Limited Warranty service.

MAIL-IN SERVICE

When shipping the unit carefully pack and send it prepaid, adequately insured and preferably in the original carton. Include a letter detailing the complaint and provide a day time phone and/or email address where you can be reached.

LIMITED WARRANTY LIMITS AND EXCLUSIONS

1) This Limited Warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The Limited Warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, or service by anyone other than a Factory Service center or other Authorized Servicer, or damage that is attributable to acts of God.

2) THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE". THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. (As examples, this excludes damages for lost time, cost of having someone remove or re-install an installed unit if applicable, travel to and from the service, loss of or damage to media or images, data or other recorded content. The items listed are not exclusive, but are for illustration only.)

3) PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.